



Tröger-2m, Tröger Modellbahnbeschriftung

Im Winkel 1a, D-14974 Ludwigsfelde,

Tel.: 03378 - 874285,

info@troeger-2m.de, www.troeger-2m.de

## Processing instructions for decals with blue carrier foil

You have just finished or rebuilt your own model and now you want to label it with this TMB lettering and marking kit? To ensure long-lasting enjoyment, please note: The working surface needs to be even and clean, especially free of grease and dust particles. Since problems may arise with the adhesion of unpainted plastics, the model is supposed to be coated with a transparent plastic primer first. After that, you will need the following devices: a bowl of water with a drop of dish detergent in it, a sharp-edged scalpel, an appropriate underlayment, paper towels and if need be a cotton bud. For better adhesion you should use flexibilizer, i. e. my article with the order number 890010 or 890110. To begin with cut out the desired object with a sharp-edged scalpel, dip it into the bowl of water for a few seconds and then lay it down on the table to let it soak. If necessary, trickle a drop of flexibilizer on the area where you want to apply the decal. Now shift the decal in the desired area and pat it dry with a paper towel very carefully. Do not wipe, otherwise you may damage the decal! If you use flexibilizer, let the decal soak for a while before you pat it dry. Always run tests in advance! Attention! Perfect grip will not be achieved until the decal has dried entirely. That will take up to 24 hours. To improve its durability, e. g. for using it outside, the model should essentially be oversprayed with clear varnish after labelling it. Also note that you ought to check the compatibility of the basecoat on a hidden part of your model. Apply several thin layers.

I hope you enjoy your product.